

The ReadMe of Window WDDM Driver

O.S. Support:

- Windows Server 2012 R2 (WHQL)
- Windows Server 2016 (WHQL)
- Windows Server 2019 (WHQL)
- Windows Server 2022 (WHQL)

Driver Installation Guide:

MSI Installation:

- Windows Server 2012 R2
 - Select MSI file in Win2012 R2
- Windows Server 2016
 - Select MSI file in Win2016
- Windows Server 2019
 - Select MSI file in Win2019
- Windows Server 2022
 - Select MSI file in Win2022

FAQ:

- Show “Code 52” on Windows Server with non-WHQL driver
 - Disable Secure Boot
 - Reference Link:

<https://techcommunity.microsoft.com/t5/windows-hardware-certification/driver-signingchanges-in-windows-10-version-1607/ba-p/364894>

Contact:

E-mail: kuohsiang_chou@aspeedtech.com

Phone: 03.575.1185 ext. 8875

ASPEED Technology Inc.